

## Drain II Air Gap Adapter



### Installation Instructions

This product is for use on 1.5" or 2" standpipes.

G.A. Murdock, Inc. highly recommends that the Drain II be solvently welded to the standpipe. We recommend PVC/ABS cement to bond the drain tube to the PVC/ABS pipe.